

SERIA
ROAD

Spacetronik **Survival**

INSTRUKCJA OBSŁUGI / USER MANUAL




PRZED ROZPOCZĘCIEM

Zanim zaczniesz uczyć się korzystania ze sprzętu, konieczne jest abyś przeczytał całą instrukcję dotyczącą bezpieczeństwa i zagrożeń.


Urządzenie wymaga utrzymywania równowagi podczas korzystania. W przypadku nieprawidłowego korzystania z urządzenia istnieje ryzyko kontuzji. Użytkownik ponosi wszelką odpowiedzialność za skutki nieprawidłowego korzystania z urządzenia. Nie stosowanie się do poniższych zasad może skutkować poważnym uszczerbkiem na zdrowiu lub nawet śmiercią. Prosimy o odpowiedzialne zachowanie, które nie będzie zagrażać Tobie, ani osobom w Twoim otoczeniu.

GŁÓWNE KOMPONENTY




- 1. Mata na stopy
- 2. Lampki sygnalizacyjne
- 3. Światła czołowe

- 4. Lampy ostrzegawcze
- 5. Włącznik
- 6. Port ładowania



ŁADOWANIE BATERII




1. Port ładowania
2. Gniazdo zasilające
3. Dioda informująca o stanie naładowania baterii

WŁĄCZANIE URZĄDZENIA

Wciśnij przycisk zasilania znajdujący się z boku obudowy urządzenia. Gdy urządzenie jest uruchomione, lampki sygnalizujące powinny się zaświecić.

RESET URZĄDZENIA




1. Połóż urządzenie na podwyższeniu tak, aby koła nie dotykały podłoża.
2. Wciśnij przycisk zasilania i przytrzymaj 3-5 sekund do czasu aż zaświecą się sygnalizatory (Caution Light)
3. Wyłącz i włącz urządzenie ponownie.

JAZDA NA DESKOROLCE


Przed każdym użyciem upewnij się, że urządzenie jest dostatecznie naładowane. Nie jeźdź gdy urządzenie nie posiada jakichś części lub jest uszkodzone.

Krok 1. Włącz urządzenie naciskając na przycisk zasilania. Upewnij się, że urządzenie jest dostatecznie naładowane.



Krok 2. Wejdź na deskorolkę


1. Postaw jedną nogę na deskorolce
2. Staraj się utrzymać deskorolkę w pozycji wyjściowej
3. Postaw drugą nogę na deskorolce



Krok 3. Poruszanie się w przód i w tył.

1. Odchyl się w tył, aby jechać do tyłu
2. Przechyl się do przodu, aby jechać w przód

UWAGA! Wystarczająco delikatne ruchy ciała aby wprowadzić urządzenie w ruch. Gwałtowne ruchy mogą spowodować utratę równowagi.



BEZPIECZEŃSTWO

1. Nie naprawiaj samodzielnie oraz nie dokonuj modyfikacji urządzenia. Czynności te dokonuje tylko autoryzowany serwis.
2. Nie uruchamiaj urządzenia, jeżeli zauważyłeś jakiegokolwiek uszkodzenia.
3. Nie używaj urządzenia, gdy zaczyna wadliwie działać, zostało upuszczone lub zanurzone w wodzie, nadmiernie nagrzewa się, pojawiają się odbarwienia, wybrzuszenia oraz gdy wystąpią inne nietypowe zjawiska. Skontaktuj się z autoryzowanym serwisem producenta.
4. Nigdy nie zostawiaj urządzenia podłączonego do gniazda zasilania bez nadzoru.
5. To urządzenie nie jest zabawką. Urządzenie jest przeznaczone dla osób powyżej 14 roku życia. Nie pozwalaj, aby dzieci nim się bawiły. Przechowuj urządzenie w miejscu niedostępnym dla dzieci.
6. Używaj urządzenia z dala od źródeł ciepła, wysokich temperatur, gorących powierzchni, bezpośredniego światła słonecznego, źródeł iskrzenia, otwartego ognia, olei oraz ostrych krawędzi.
7. Nie używaj urządzenia w otoczeniu zawierającego łatwopalne, wybuchowe lub toksyczne substancje.
8. Nie używaj substancji chemicznych do czyszczenia urządzenia.
9. Po każdym użyciu wyłącz urządzenie.


10. Nie zanurzaj całego urządzenia w wodzie lub w innych cieczach. Nie używaj w pobliżu wody.
11. Przed czyszczeniem lub przenoszeniem urządzenia, wyłącz je.
12. Nie używaj urządzenia do innych celów, niż do których zostało ono zaprojektowane.
13. Trzymaj urządzenie z dala od ostrych przedmiotów.
14. Nie używaj urządzenia i nie dotykaj zasilacza, mając mokre lub wilgotne ręce.
15. Maksymalna dopuszczalna waga użytkownika urządzenia to 100 kg.
16. Dla własnego bezpieczeństwa używaj kasku i ochraniaczy.
17. Nie noś luźnych ubrań, które mogą przeszkadzać w kontroli urządzeniem oraz które może zaczepiać się o koła.
18. Nie kładź innych przedmiotów na urządzeniu, kiedy z niego korzystasz.
19. Korzystaj z urządzenia tylko na płaskich i twardych nawierzchniach. Unikaj przeszkód, nierównych powierzchni, piasku, trawy, lodu, śliskich i mokrych powierzchni, dziur, stopni, krawężników, które mogą spowodować utratę kontroli i upadek.
20. Nie korzystaj z urządzenia na stromych powierzchniach.
21. Zadbaj o to aby obydwa koła zawsze dotykały ziemi.
22. Uważaj, aby jedno koło nie spadło z krawężnika.
23. Jeźdź ostrożnie po terenie, po którym wcześniej nie jeździłeś.
24. Zawsze uważaj na innych użytkowników drogi, po której jeździsz. Omijaj, wymijaj i wyprzedzaj przechodniów, rowerzystów itp. w bezpiecznej odległości.
25. Poruszaj się z taką prędkością, przy której masz pewność kontroli. Bądź zawsze gotów do zatrzymania się.
26. Przestrzegaj przepisów prawa i zasad na terenie, na którym używasz urządzenia.
27. Urządzenie nie jest przeznaczone do korzystania w ruchu drogowym. Korzystaj z niego z dala od ruchu drogowego.
28. Skręcaj z ostrożnością. Szybka zmiana kierunku może doprowadzić do stracenia równowagi.
29. Urządzenie jest przeznaczone dla jednej osoby. Nie należy korzystać jednocześnie z inną osobą, nie wolno trzymać dziecka w ramionach oraz w nosidełku. Kobiety w ciąży nie powinny korzystać z urządzenia.

BEFORE START

Before learning to start your vehicle, you must read and follow all instructions and warnings in this User Manual. It is important that you follow all safety warnings and cautions that appear throughout the User Manual and that you use good judgement when you ride your Scooter.


The Scooter is a self-balancing, personal scooter that uses balancing technology. Balancing technology cannot prevent injury if you do not ride the scooter safely. Whenever you ride the Scooter, you risk death or serious injury from loss of control, collisions and falls. To reduce risk of injury, you must read and follow all instructions and warnings in the user manual.

MAIN COMPONENTS




- 1. Foot Mat
- 2. Indicator Lights
- 3. Headlights

- 4. Caution Light
- 5. Power Button
- 6. Charging Port




CHARGING YOUR BATTERIES



POWERING ON THE SCOOTER

Power on your Scooter by pressing the Power button. The Power button is located on the back side of the Scooter. The indicator lights will illuminate to indicate the power is ON

RESETTING THE SCOOTER




1. Put the Scooter on a level surface where the wheels do not make contact with the ground.
2. Press the Power Button for 3-5 seconds until caution light flashes
3. Turn OFF the scooter and turn ON again

RIDE ON SCOOTER


Before riding, make sure your Scooter is fully assembled and charged. Inspect your Scooter before each use. Don't ride if any part is loose or damaged.

Step 1. Power ON the Scooter by pressing the power button. Make sure the Battery Status Indicator is on.




Step 2. Getting on the Scooter

1. Place one foot on the foot mat.
2. Try to keep scooter steady and leveled.
3. Place your other foot on the foot mat.



Step 3. Moving forward and backwards

1. Keep scooter still by remaining level when standing on it.
2. SLIGHTLY lean your body forward or backward to enable the scooter to move.



SAFETY

1. Always wear proper attire when using the Scooter, do not wear loose clothing that can catch in tires and prevent proper steering.
2. Never place anything on the foot mats except your feet.
3. Avoid obstacles and surfaces that could result in a loss of balance or traction and cause a fall.
4. Use caution when riding over any terrain change such as pavement to sand, grass or speed bumps.
5. Avoid riding across steep slopes. Maintain both tires in contact with the ground.
6. Avoid holes, curbs, steps and other obstacles,
7. Avoid riding over any surface where the bottom of the Scooter may impact any object.

8. When using in sidewalk, make sure that one wheel does not drop off the curb.
9. Use caution when riding in new environments.
10. Make sure you leave enough Wheel clearance.
11. Be careful and considerate of others while riding
12. Always ride under control at a speed that is safe for you and those around you.
13. Always be prepared to stop.
14. Respect pedestrians by always yielding the right of way.
15. Avoid startling pedestrians. When approaching from behind, announce yourself and slow down to walking speed when passing. Pass on the left whenever possible. When approaching a pedestrian from the front, stay to right and slow down.
16. In heavy pedestrian traffic conditions, slow down and proceed at the pace of pedestrian traffic. Pass only if there is ample space to do so safely. Don't weave in and out of pedestrian traffic.
17. When riding with other Scooter riders, maintain a safe distance, identify hazards and obstacles, and don't ride side by side unless there is plenty of room left for pedestrians.
18. Cross roads at designated crosswalks or signaled intersections. Don't jaywalk/ride.
19. Only travel on a road when a pedestrian way is not available or when sidewalk use is not allowed. Don't ride your Scooter on private property (inside or outside) unless you have obtained permission to do so.
20. Learn about obey applicable local laws and regulations.
21. Don't allow any person to use your Scooter unless that person has carefully read this manual.
22. Use caution on slopes. Use caution when ascending, descending or crossing slopes. When riding across any slope, lean uphill to maintain balance.

23. Always turn slowly and with caution. Fast turns can lead to loss of control and falls.
24. No passengers. The scooter is designed for one rider. Don't ride double or carry any passengers. Don't carry a child in your arms or in a child carrier while riding. Expectant mother should not ride the Scooter.
25. Don't step off the scooter while moving. Always come to a stop before stepping off.
26. Be alert. As with any other transportation device, you must be mentally alert to safely ride. Do not attempt to ride if you are ill or if you cannot comply fully with the instructions and warnings in this manual. Don't ride under the influence of alcohol or drugs. Avoid distractions. Don't use a mobile phone or engage in any other activity that might distract you or interfere with your ability monitor your surroundings while riding.
27. When riding, keep both feet on the foot mats. Be relaxed. Ride in a relaxed position with your knees and elbows slightly bent and head up
28. Don't ride backwards for long time.
29. Riding on the road. The Scooter is not intended or recommended for primary use on roads. Be careful when you must ride on the road or must cross the road.

[PL] Certyfikat CE: produkt bezpieczny, zgodny z wymaganiami dyrektyw nowego podejścia w UE:

Dyrektywa: 2014/30/EU (EMC), 2014/35/EU (LVD)

Certyfikat RoHS: produkt nie zawiera substancji szkodliwych i materiałów niebezpiecznych:

Dyrektywa: 2011/65/EU

[EN] CE certificate: Safe product, complies with the requirements of new EU approach directives:

Directive: 2014/30/EU (EMC), 2014/35/EU (LVD)

RoHS certificate: the product does not contain harmful substances and dangerous materials:

Directive: 2011/65/EU



PRODUCENT/SERWIS

DMTrade

Wiśniowa 36

64-000 Kościan

www.spacetronek.pl

www.dmtrade.pl